## PFX2400 SERIES



## CAPACITOR TESTER PFX2400 Series

. . . .

Tester for EDLC (Electric Double Layer Capacitor) test Fully independent channel operations LAN interface handles setting, operation and data collection Capable of measuring voltage of reference electrode Centralized management by dedicated application software Data sampling at 1 ms or 100 ms






# Capacitor Tester **PFX2400** SERIES

The Capacitor Tester PFX2400 Series is dedicated to design charge/discharge testers for electric double layer capacitors. The voltage rating is 5V, targeting single-cell batteries, and a lineup of 4 models is available: 5A/12-ch, 35A/4-ch, 70A/2-ch, and 140A/1-ch. In recent years, the electric double layer capacitor has been increasing its capacity, and it can be used in electric automobiles as power sources for starting the engine and for assistance during acceleration. Wider use of these capacitors is expected as a new energy source for raising automobile fuel economy and also improving exhaust quality. The Capacitor Tester PFX 2400 Series meets the need for more advanced and specialized tests related to the two key issues facing the wider use of electric double layer capacitors: power storage technologies and power management (energy optimization).

### Series line-up




## CAPACITOR TESTER PFX2400 SERIES

## Compliant with IEC 62576(2009) / JIS D1401 !

Electric double layer capacitors for use in hybrid electric vehicles - Standards for charge/discharge characteristic tests

### Compliant with IEC 62576(2009) / JIS D1401

The PFX2400 series can perform following tests.



## The Charge-Discharge mode for the diverse applications

Charging method (Constant Current - Constant Voltage / Constant Current / Constant Power / Step )

Discharge method (Constant Current - Constant Voltage / Constant Current / Constant Power / Step )

### **High-speed data sampling**

Adopting the LAN communication interface realizes the simultaneous data sampling of the current and voltage.

### Fully independent channel operations

The absolute independence of operations on all channels allow you to conduct the combined testing of the different characteristics of EDLC's.

In consideration of synchronization with a thermostatic chamber, a synchronization function has been provided which performs control to extend the rest time.

### **Energy-saving designs**

The PFX2400 controls to keep constant of the internal loss. While in the charging state, and it realizes the low power consumption.

## Wide range of the AC input


The PFX2400 can be used at the location from the benchtop to the production line wherever the input power supply of 100Vac to 240Vac is provided.

## The dedicated software applies to the wide versatility of testings.

Optional application software (SD008-PFX2400) is required to operate the PFX2400 Series.

The test pattern of the "JIS D 1401" and "JIS C 5160" has been provided in the software, so you can easily set and execute the test conditions of the capacitor complied to the JIS standard. Refer to page 4 for details.

## System Configuration



Not included in the PFX2411. They are optional, or users are requested to prepare them separately.


## Capacity of test samples (capacitors)

When selecting a PFX2400 Series model, use the table below as a guideline to the capacities of the test capacitors.

Model	PFX2411	PFX2421	PFX2431	PFX2441
Electrostatic capacity	0.1F or higher	0.5F or higher	1F or higher	2F or higher

### Setting the test conditions

If the data sampling interval is 1 ms, set the discharge current based on the test sample (capacitor) electrostatic capacity so that the time from starting discharge to cut off is 0.1 s or longer. If the data sampling interval is 100 ms, set the discharge current based on the test sample (capacitor) electrostatic capacity so that the time from starting discharge to cut off is 10 s or longer.



## **Application software** D008-PFX2400

The SD008-PFX2400 package contains following three application software.

### CPChecker2400

Using the PFX2400 series with this application software, you can create test conditions for the cycle test, voltage hold test and charge/discharge efficiency test and execute the tests.

An operation panel is provided independently for each channel, and individual test per channel can be executed. For setting the test conditions, selections for JIS D 1401 and JIS C 5160 are provided. You can easily set the capacitor test conditions based on the JIS. The test results are saved in text files (CSV format); so it can be used with other spreadsheet software.

a des una	The second statements
	The second
A DESCRIPTION OF A DESC	
1828	
and the second se	
CONTRACTOR OF THE OWNER O	
Initial 12	The second se
and the second se	and a second s
tanting () (a	and a second s
Comment of the second second	
starball 12	Territoria Statements
	SS 95 II one II states (3 termination 2 test
A land 1 / an an and a second	THE PARTY AND ADDRESS OF THE PARTY ADDRESS OF THE P
manual contract of the second s	
No. Los Martin Contraction of the loss of	
august and a second	The new York The Contract of the second seco
And a state of the	The Party of the P
	ALL STATE AND A ST
	ALALIANS ALALIANSI AND
THE REAL PROPERTY AND ADDRESS OF	AND
1 B B B B B	
and a second	All and the second seco
Tax I merel Ballin	

- Multi-channel control<sup>\*1</sup>
- Channel number assignment
- Test condition configuration and saving
- Test start, stop, pause, and alarm reset
- Test result display
- Test result file creation and saving (CSV format)
- Measured value monitoring (charge and discharge current, terminal voltage, and reference electrode voltage)
- HOVP/HUVP voltage display
- Rest hold
- The number of channels that can be controlled varies depending on the data acquisition interval. For example, if a test cycle is 600 s, up to 96 channels can be controlled under the following conditions.
  Δ V: 0.5 % of the charge-discharge voltage
  Δ 1: 0.5 % of the charge-discharge current
  Δ T: 10 s

#### [System requirements]


#### CPChecker2400 and CPChecker2400 Plus

- PC running Microsoft Windows XP Service Pack 3 or later, Windows Vista, or Windows 7
- Microsoft Windows Installer 3.1 (may need to be installed on Windows XP; included on the CD)
- Microsoft .NET Framework 3.5 SP1 (included on the CD)
  Microsoft Chart Controls for Microsoft .NET Framework 3.5 (included on the CD)
- 2 GB or more of memory
- Monitor with a resolution of 1280 x 1024 dots or higher
- 100 MB or more of free hard disk space (the amount of additional space that is needed depends on the type of data you need to save)
- CD-ROM drive
- Mouse or other pointing device
- 10BASE-T or 100BASE-TX LAN port
- \*1 If you only need to use one channel without a switching hub, you can connect the PFX2400 Series directly to a PC using a crossover LAN cable.

#### CPChecker2400 Plus

CPChecker 2400 Plus is software that graphs the test data that was created by CPChecker 2400 on the screen or printing. In addition to the test data graphs, it can also display the test data values, electrostatic capacities, and other values calculated from the test data, making a range of data analysis possible.

CAPACITOR TESTER PFX2400 SERIES



- Graph display and graph overlay for each test cycle
- Display of test data acquired with CPChecker 2400
- Display and printing of transition graphs for all cycles
- Recalculation of the initial internal resistance and internal resistance following changes to the calculation conditions

#### IP Configuration Tool \*2

The IP Configuration Tool is to set the IP address and channel number of the Capacitor Tester PFX2411. The IP address<sup>\*3</sup> and channel number can be changed by this software.

		Carve 184		100	the second secon	hit Him		
16	P. ANTONIA	PACADOWN	Of R.	And I	The state of the second	ALC: NOT THE	OK NO	- 10-
	VALUE AND DECK	002646.6854820	1040	1000	102 104 10-	HOR.		-98-
ъ	10011202101-00	ID-TRACKETAP'	10	(8.84)	102 104 10	1000		120
2	100710841084	DAME OF BRIDE	10.00	(MAL)	10000	Corr. Co		100
82	101108-10-12	10.10.24.4576.85	6.0	1.00	I don't had be	1905		1.81
2	100100-0010-00	INTRACIONALE	CONTRACT	CARL	100 100 100	1000		020
	1021066.308	00.74 84 14 14 14	-	0.00	102 104 10	1000		Cart
	1021041062	10120-04-04/04/04/10	Cite	82	144 VM 14	-Cart 3-		1.911
1	102108-10-2	00.20-6A.40-75-FE	1.1		18218810	0.000		100
40	202104305	00,25-64,46,74 (0)	2.185	(Ann.)	14710116	0.000-		C.R.C.
Ħt.	1927 1988 2404	10-25-44-46-76-78		OLAN.2	107204.20	1383.2		0.00
	10021044-0042	10115-01-02-04-07						

- IP address:192.168.0.0 to 192.168.255.254
- Channel number: 0 to 256
- \*3 When IP Configuration Tool is not used, it is necessary to set the IP address and subnet mask of the personal computer with which CPChecker2400 is used according to the range of IP address of the PFX2400 series.

#### IP Configuration Tool

- PC running Microsoft Windows XP Service Pack 3 or later, Windows Vista, or Windows 7
- Microsoft Windows Installer 3.1 (may need to be installed on Windows XP; included on the CD)
- Microsoft .NET Framework 3.5 SP1 (included on the CD) 256 MB or more of memory
- Monitor with a resolution of 1024 x 768 dots or higher
- CD-ROM drive
- Mouse or other pointing device
- 10BASE-T or 100BASE-TX LAN port Others
- LAN cables (the number of straight cables required is the number of PFX2400 channels that you want to use and one straight cable for the PC)\*1
- · Switching hub (the minimum number of ports required is the number of PFX2400 channels that you want to use and one port for the PC) PFX2400 Series
- Adobe Reader 6 or later (required to view the PDF version of the operation quide)

## Specifications

Item/Model		PFX2411	PFX2421	PFX2431	PFX2441			
Charge function								
	СС		Constant cu	rrent charge				
	CC-CV	Constant current charge until the specified voltage is reached, followed by constant voltage charge						
Charge method	СР		Constant po	ower charge				
	Step	Charging is	performed in steps that are corr	binations of the CC, CC-CV, and	d CP modes			
	CV time	In CC-CV mode	e, charging stops when the CV ti	me elapses after charging switch	nes to CV mode			
Cutoff condition	Voltage	In CC mode, charging stops when the specified voltage is reached						
Outon condition	Current	In CC-CV mode, cha	rging stops when the specified of	urrent is reached after charging	switches to CV mode			
	Charge time	Charging stops when the specified time elapses after charging has been started						
Rest end condition	Rest time		g stops when the specified time					
Disaharma funation	Synchronization	I he p	ause extension feature is used to	o synchronize the stopping of ch	arging			
Discharge function	СС		Constant our	ent discharge				
	CC-CV	Constant current dis	scharge until the specified voltag		nt voltage discharge			
Discharge method	CP	Constant ouriont di		ver discharge	in voltage discharge			
	Step	Discharging	is performed in steps that are co	· · · · · · · · · · · · · · · · · · ·	d CP modes			
	CV time							
	Voltage	In CC-CV mode, discharging stops when the CV time elapses after discharging switches to CV mode In CC mode, discharging stops when the specified voltage is reached						
Cutoff condition	Current	In CC-CV mode, discharging stops when the specified current is reached after discharging switches to CV mode						
	Charge time	Discharging stops when the specified time elapses after discharging has been started						
	Rest time	Discharging stops when the specified time elapses after discharging has been started Discharging stops when the specified time elapses after discharging has been paused						
Rest end condition	Sync commands during extended idling							
Measurement function	, <u> </u>							
Voltage	Measuring interval		1 ms or	100 ms				
Current	Measuring interval		1 ms or	100 ms				
Reference electrode voltage	Measuring interval	1 ms or 100 ms	_	_	_			
Time			Elapsed time from	n the start of test				
Cycle count			Counts the total	number of cycles				
Protection function			>					
Overvoltage (overcharge)	Software OVP	Ola ana divida ana dia a			man and in the second			
protection	Hardware OVP	Cleared when the corresponding channel's output is turned off and when a reset command is received						
Overcurrent protection	Software OCP	Cleared when the corresponding channel's output is turned off and when a reset command is received						
Overheat protection (OHP)		Activated when the heatsink temperature is at 90 °C $\pm$ 5 °C. Cleared when the corresponding channel's output is turned off and when a reset command is received						
Undervoltage(Overdischarge)	Software UVP	Cleared when the corresponding channel's output is turned off and when a reset command is received Cleared when the corresponding channel's output is turned off and when a reset command is received						
protection	Hardware UVP	Cleared when the corresponding channel's output is turned on and when a reset command is received     Cleared when the corresponding channel's output is turned off and when a reset command is received						
External alarm input			Testing stops at the		rien a leser command is leceived			
Display function (status mor	nitoring)							
	POWER	A test is in progress or the P	FX2400 series is ready for a tes	to be executed. The POWER/S	TANDBY LED lights in green.			
Power status	STANDBY				· · · ·			
	CHARGE	The PFX2400 series is in standby mode or the system is ready to be stopped. The POWER/STANDBY LED lights in orange. Charging. The CHARGE/DISCHARGE/REST LED lights in red.						
Charge and discharge	DISCHARGE	Discharging. The CHARGE/DISCHARGE/REST LED lights in red.						
status	REST		Resting. The CHARGE/DISCHA					
	СС	Constant current mode. The CC/CV/CP LED lights in red.						
Control status	CV	Constant voltage mode. The CC/CV/CP LED lights in red.						
	СР	Constant voluge mode. The CC/CV/CP LED lights in orange.						
	ALARM	Alarm dete	cted. Protection function activate	d. The ALARM/WARNING LED I	ights in red.			
Alarm	WARNING	Alarm detection warni	ng. A warning to indicate that a p		ed if a test is executed.			
Botod output			I NE ALARM/WARNIN	G LED lights in orange.				
Rated output		10-6	1.00	Och	1.04			
Number of outputs Charge current range		12ch 0.0000A to 5.0000A	4ch 0.000A to 35.000A	2ch 0.00A to 70.00A	1ch 0.00A to 140.00A			
Charge voltage range		0.0000A to 5.0000A		0.00A to 70.00A	0.00A 10 140.00A			
Charge power range		0.1W to 25.00W	0.1W to 175.0W	1W to 350W	1W to 700W			
Discharge current range		0.0000A to 5.0000A	0.000A to 35.000A	0.00A to 70.00A	0.00A to 140.00A			
Discharge voltage range			to 5.0000V		0 5.0000V			
Discharge power range		0.01W to 25.00W	0.1W to 175.0W	1W to 350W	1W to 700W			
Maximum charge and disch	arge power	25.0W	175.0W	350W	700W			
Setting accuracy								
	Range	0.0000A to 5.0000A	0.000A to 35.000A	0.00A to 70.00A	0.00A to 140.00A			
	Accuracy	±(0.07% of set +1mA)	±(0.15% of set +15mA)	±(0.15% of set +30mA)	±(0.15% of set +60mA)			
Current setting	Resolution	100µA	1mA	10mA	10mA			
		· - • • • •						
		1.5mArms or less	1.5mArms or less 20mArms or less 40mArms or less 60mArms or 0.0000V to 5.0000V					
	Ripple*1 Range	1.5mArms or less			60mArms or less			
	Ripple*1	1.5mArms or less		o 5.0000V	bomarms or less			
Voltage setting	Ripple*1 Range	1.5mArms or less	0.0000V t ±(0.07% of	o 5.0000V	oumarms or less			
Voltage setting	Ripple*1 Range Accuracy*2	1.5mArms or less	0.0000V t ±(0.07% of 100	o 5.0000V set + 1.5mV)	ouniarins or less			
Voltage setting	Ripple*1 Range Accuracy*2 Resolution	1.5mArms or less	0.0000V t ±(0.07% of 100	ο 5.0000V set + 1.5mV) 0μΑ	1W to 700W			
Voltage setting Power setting	Ripple*1 Range Accuracy*2 Resolution Ripple*1		0.0000V t ±(0.07% of s 100 3mVrm:	o 5.0000V set + 1.5mV) 0μA s or less				
	Ripple*1 Range Accuracy*2 Resolution Ripple*1 Range	0.01W to 25.00W	0.0000V t ±(0.07% of s 100 3mVrm: 0.1W to 175.0W	o 5.0000V set + 1.5mV) 0µA s or less 1W to 350W	1W to 700W			

## CAPACITOR TESTER PFX2400 SERIES

## Specifications

Item/Model		PFX2411	PFX2421	PFX2431	PFX2441			
Measurement accuracy								
	Range	0.00000A to 5.00000A	0.000A to 35.000A	0.000A to 70.000A	0.000A to 140.000A			
	Accuracy *1 *2	±(0.07% of rdng + 1mA)	±(0.15% of rdng + 15mA)	±(0.15% of rdng + 30mA)	±(0.15% of rdng + 60mA)			
Current measurement	Resolution	10µA	100µA	1mA	1mA			
	Sampling time		1 ms or	100 ms				
	Range	-0.50000V to 5.0000V						
Voltage measurement	Accuracy *1 *2	±(0.07% of rdng + 1.5mV)						
voltage measurement	Resolution	10µV						
	Sampling time	-0.50000V to 5.00000V						
	Range		_	_	_			
Reference electrode	Accuracy *1 *2	±(0.07% of rdng +1.5mV)	_	_	_			
voltage measurement	Resolution	10µV	_		_			
Protection function	Sampling time	1 ms or 100 ms		—				
Protection function Overvoltage (Overcharge) p	rotaction *2							
Overvoltage (Overcharge) p	Setting range		0.10V t	o 6.00V				
	Resolution	10mV						
Hardware OVP	Setting accuracy	±300mV						
	Operating time	100ms or less						
Setting range								
	Resolution	-0.6000V to 5.1000V 100µV						
Software OVP	Setting accuracy	±(0.07% of set + 1.5mV)						
	Operating time	100ms or less						
Undervoltage (Overdischarg								
	Setting range	_		-1.80V to 4.00V				
	Resolution	_		10mV				
Hardware UVP	Setting accuracy	_		±300mV				
	Operating time	_	100ms or less					
	Setting range		-0.6000V 1	to 5.1000V				
0.4	Resolution	-0.000V 10.000V						
Software UVP	Setting accuracy	±(0.07% of set + 1.5mV)						
	Operating time	100ms or less						
Overcurrent protection								
	Setting range	0.0000A to 5.1000A	0.000A to 35.700A	0.00A to 71.40A	0.00A to 142.80A			
	Resolution	100µA	1mA	10mA	10mA			
Software OCP	Setting accuracy	±(0.07% of set +1mA)	±(0.15% of set +15mA)	±(0.15% of set +30mA)	±(0.15% of set +60mA)			
	Operating time			or less				
Built-in fuse		7A	40A	40A×2	40A×4			
Overheat protection (inside the equipment)								
OHP Operating temperature		A	Activated when the built-in heatsi	nk temperature is at 90 °C ± 5 °	C			
AC input overcurrent protection		Through the power switch (breaker) or the AC input fuse						
External alarm input								
Allowable input voltage		+12V						
Input level		HI level : 2 V to 12 V / LOW level : OPEN or 0 V to 1 V						
Minimum pulse width		50ms						
Interface								
Ethernet(LAN)		Automatic 10BASE-T/100BASE-TX selection						
Connector			RJ	J45				
General specifications								
Nominal input rating / Input	voltage range			to 60Hz / 90Vac to 250Vac				
		Per channel:Approx. 100 VA	Per channel:Approx. 500 VA	Per channel:Approx. 1000 VA	00			
Power consumption		(when charged at 5 V, 5 A)	(when charged at 5 V, 35 A)	(when charged at 5 V, 70 A) For all 2 channels:2000 VAmax	2000 VAmax			
		For all 12 channels:2000 VAmax (when all channels are charged at 5 V, 5 A)			(when charged at 5 V, 140 A)			
Operating temperature and	humidity range	(when all channels are charged at 5 V, 5 A) (when all channels are charged at 5 V, 35 A) (when all channels are charged at 5 V, 70 A) 0°C to +40°C, 20%rh to 85%rh (no condensation)						
Storage temperature and hu		-20°C to +60°C, Within 90%rh (no condensation)						
Operating environment		Indoor. Overvoltage category II						
Elevation		Up to 2000m						
Isolation voltage	Across the I/O terminals and chassis							
Ŭ	Across the AC input and chassis							
Insulation resistance	Across the DC output and chassis							
Withstand voltage	Across the AC input and chassis							
Leakage current		3.5mA or less						
Voltage dip tolerance		Approx.50ms 10 ms or more (when the output current is 50 %)						
Safety *4				standard: EN61010-1, Class I, F				
Dimensions				nsions on page 8.	· · · · · · · · · · · · · · · · · · ·			
weight		Approx.23kg (50.71 lbs)	Approx.27kg (60 lbs)	Approx.26kg (57.32 lbs)	Approx.26kg (57.32 lbs)			
	Power code			1				
	OUTPUT terminal cover	_	4sets	2sets	1set			
	M8 output terminal screw	_	8sets	4sets	2sets			
Accessories	M4 output terminal screw	_	8pcs.	4pcs.	2pcs.			
	Sensing connector	_	-	2pcs.	1pc			
	OUTPUT connector	12pcs.	_		-			
	Operation manual		· .	1				

\*1 Ambient temperature: 18 to 28°C \*2 Measurable range: Within the ranges indicated above \*3 The capacitance of the connected DUT (capacitor) must be 0.1 F or more for the PFX2411, 0.5 F or more for the PFX2411, 1F or more for the PFX2411, 0.5 F or more for the PFX2411, 0.5 F or more for the value a sampling is performed at 1 ms intervals, the discharge current must be such that the time between when discharging starts and when it finishes is 0.1 s or more. When data sampling is performed at 100 ms intervals, the discharge current must be such that the time between when discharging starts and when it finishes is 0.1 s or more. When data sampling is performed at 100 ms intervals, the discharge current must be such that the time between when discharging starts and when it finishes is 0.5 s or more. When data sampling is performed at 100 ms intervals, the discharge current must be such that the time between when discharging starts and when it finishes is 0.5 s or more. When data sampling is performed at 100 ms intervals, the discharge current must be such that the time between when discharging starts and when it finishes is 10 s or more. \*4 Does not apply to specially ordered or modified products.

## **Ordering information**

#### Main part

Model	Part	Remarks
PFX2411	Capacitor Tester	5V/5A 25W×12ch
PFX2421	Capacitor Tester	5V/35A 175W×4ch
PFX2431	Capacitor Tester	5V/70A 350W×2ch
PFX2441	Capacitor Tester	5V/140A 700W×1ch

#### Option

	Model	Part	Remarks
	SD008-PFX2400	Application software	Required to operate the PFX2400 Series
	TL20-PFX	Output cable for PFX2411	10Vdc/6A AWG16 About 7m in length
	TL21-PFX	Output cable for PFX2421	10Vdc/80A AWG4 About 5m in length
-	TL22-PFX	Output cable for PFX2431	10Vdc/80A AWG4 About 5m in length
	KRB4	Rack mount brackets	For inch-type rack (EIA)
-	KRB200	Rack mount brackets	For metric type rack (JIS)

[Caution] Application software (SD008-PFX2400) is required in order to operate the PFX2400 Series.


Also, the system is not provided with an output cable for connecting the sample (capacitor). Prepare an output cable that is suitable for the sample (capacitor). A separate load cable is required for each channel that is used.

## **Dimensions**





TL21-PFX





1-1-3, Higashiyamata, Tsuzuki-ku, Yokohama, 224-0023, Japan

Phone: (+81) 45-593-7570, Facsimile: (+81) 45-593-7571, www.kikusui.co.jp

KIKUSUI AMERICA, INC.1-877-876-2807 www.kikusuiamerica.com 2975 Bowers Avenue, Suite 307, Santa Clara, CA 95051 KIKUSUI Phone: 408-980-9433 Facsimile: 408-980-9409

KIKUSUI TRADING (SHANGHAI) Co., Ltd. www.kikusui.cn Room 216, Building 4, No.641, Tianshan Road, Shanghai City, China **KIKUSUI** Phone: 021-5887-9067 Facsimile: 021-5887-9069

For our local sales distributors and representatives, please refer to "sales network" of our website. Printed in Japan

#### Distributor:

All products contained in this catalogue are equipment and devices that are premised on use under the supervision of qualified personnel, and are not designed or produced for home-use or use by general consumers. ■ Specifications, design and so forth are subject to change without prior notice to improve the quality. subject to change and production may be discontinued when necessary. I product names, company names and brand names contained in this catalogue represent the respective registered trade name or trade mark. I Colors, textures and so forth of photographs shown in this catalogue may differ from actual products due to a limited fidelity in printing. Although every effort has been made to provide the information as accurate as possible for this catalogue, certain details have unavoidably been omitted due to limitations in space. If if you find any misprints or errors in this catalogue, it would be appreciated if you would inform us. If Please contact our distributors to confirm specifications, price, accessories or anything that may be unclear when placing an order or concluding a purchasing agreement.